

HESAI

www.hesaitech.com

JT128

128-Channel Mechanical Lidar User Manual

Classification: CO (Public)

Doc version: J01-en-260310

Table of Contents

■ About this manual	1
Access to this manual	1
Technical support	1
Legends and format	1
■ Safety notice	2
Special warnings	2
Operating environment	3
Personnel	5
Installation and operation	5
Repair	9
1 Introduction	10
1.1 Applicability	10
1.2 Operating principle	10
1.3 Basic structure	11
1.4 Channel distribution and coordinate systems	13
1.5 Specifications	16
2 Setup	19
2.1 Mechanical installation	19
2.1.1 Exterior dimensions	19
2.1.2 Recommended installation	21
2.1.3 Notes on screw installation	22
2.2 Electrical interface	23
2.2.1 Pin description	23
2.2.2 Connector use	25
2.3 Cable	27

2.3.1 Ports	28
2.4 Network settings on the host computer	29
2.4.1 In Windows	30
2.4.2 In Ubuntu	33
2.5 Tools	36
3 Data structure	37
3.1 Point Cloud Data Packet	38
3.1.1 Ethernet Header	38
3.1.2 Point cloud UDP data	39
3.1.3 Ethernet tail	47
3.1.4 Point cloud data analysis method	48
4 Parameter interfaces	51
4.1 Network connection	51
4.1.1 Source	51
4.1.2 Destination	52
4.2 Functional settings	53
4.3 State settings	56
4.4 Time sync	57
4.5 Lidar info	58
4.6 Operation Statistics	59
4.7 Upgrade	59
5 Maintenance	60
6 Troubleshooting	62
Appendix A: Channel distribution data	65
A.1 Angular position and performance	65
A.2 Angle correction file	72
Appendix B: Absolute time of point cloud data	74

B.1 Source of absolute time	74
B.1.1 GNSS as the clock source	74
B.1.2 PTP as the clock source	75
B.2 Absolute time of the Point Cloud Data Packets	76
B.3 Start time of each block	76
B.4 Laser firing time of each channel	77
Appendix C: Power supply requirements	79
C.1 Input voltage	79
C.1.1 Estimate the cable voltage drop	79
C.1.2 Avoid overvoltage	80
C.2 Input power	81
C.3 Power up/down	81
Appendix D: Optical center offset correction	82
D.1 Cause for correction	82
D.2 Definition of correction	82
D.3 Formula	84
Appendix E: Legal notice	85

■ About this manual

Please make sure to read through this user manual before your first use and follow the instructions herein when you operate the product. Failure to comply with the instructions may result in product damage, property loss, personal injuries, and/or a breach of warranty.

Access to this manual

To obtain the latest version, please do one of the following:

- Visit the Download page of Hesai's official website: <https://www.hesaitech.com/downloads/>
- Contact your sales representative of Hesai.
- Contact Hesai technical support at service@hesaitech.com.

Technical support

If your question is not addressed in this user manual, please contact us at:

- service@hesaitech.com
- <https://www.hesaitech.com/technical-support/>
- <https://github.com/HesaiTechnology>

Legends and format



Warnings: Instructions that must be followed to ensure safe and proper use of the product.



Notes: Additional information that may be helpful.

Names of data fields are in monospace font.


For example: **Distance** represents the Distance field.

■ Safety notice

- Please make sure to read through this safety notice and follow all the instructions and warnings. Failure to comply with the instructions and warnings may result in product damage, property loss, and/or personal injuries.
- Please check the certification information on the product's nameplate. If an agreement has been made not to present certification information on the nameplate, please follow the agreed-to arrangements.
- If you incorporate this lidar product into your product(s), you are required to provide this user manual (or access to this user manual) to the intended users of your product(s).
- This lidar product is intended as a component of an end product. The end-product supplier is responsible for assessing the risk of use in accordance with applicable standards and informing the intended user of safety-related information.
- Should there be other agreements with specific users, the other agreements shall apply.
- Before using a product, please confirm with Hesai the development maturity of the product in a timely manner. For products still in development, Hesai makes no warranty of non-infringement nor assumes any responsibility for quality assurance.

Special warnings

Laser safety



Hot surface



Hot parts!

Burned fingers when handling the parts.

Wait one-half hour after switching off before handling the parts.

Abnormalities

In any of the circumstances listed below, stop using the product immediately:

- If you suspect malfunctions of or damage to the product, with symptoms such as noticeable noise or vibration.
- If you or people in the nearby environment feel discomfort.
- If any device or equipment in the nearby environment malfunctions.

Meanwhile, contact Hesai or an authorized Hesai service provider for more information on product disposal.

Prohibition of disassembly

Unless expressly agreed to in writing by Hesai, do NOT disassemble the product.

Operating environment

Radio frequency (RF) interference

- Before using the product, make sure to read all the signs and notices on the product enclosure (including the nameplate). If specific users require not presenting certification information on the nameplate, please follow the agreed-to arrangements.

Vibration

- If significant mechanical shocks and vibration exist in the product's operating environment, please contact Hesai's technical support to obtain the shock and vibration limits of your product model. Exposure to over-the-limit shocks or vibration may damage the product.
- Make sure to package the product in shock-proof materials to avoid damage during transport.

Explosive atmosphere and other air conditions

- Do NOT use the product in any area where a potentially explosive atmosphere is present, such as where the air contains high concentrations of flammable chemicals, vapors, or particulates (including particles, dust, and metal powder).
- Do NOT expose the product to environments that have high concentrations of industrial chemicals, including liquefied gases that are easily vaporized (such as helium). Such exposure can damage or impair product functionality.

Chemical environment

Do NOT expose the product to corrosive or strong polar chemical environments (such as liquids or gases), including but not limited to strong acids, strong bases, esters, and ethers. This is to avoid damage to the product (including but not limited to water resistance failure).

Ingress protection (IP)

Please check the product's user manual for its IP rating (refer to [Section 1.5 Specifications](#)). Make sure to avoid any ingress beyond that rating.

Operating temperature

Please check the product's user manual for its operating temperature (refer to [Section 1.5 Specifications](#)). Make sure not to exceed the operating temperature range.

Recommended storage conditions

Please store the product in a dry and well-ventilated place. The recommended ambient temperature is $23 \pm 5^{\circ}\text{C}$, with relative humidity between 30% and 70% RH.

Light interference

Certain precision optical instruments may interfere with the laser light emitted from the product. Please check all the instructions for these instruments and take preventive measures if necessary. For example, protective leather covers are provided for certain product models; when these lidars are temporarily not used for measurement, the leather covers can be applied to block laser light emission.

Personnel

Recommended operator qualifications

The product should be operated by professionals with an engineering background or experience in operating optical, electrical, and mechanical instruments. Always follow the instructions in this manual throughout operation. If needed, please contact Hesai for technical support.

Medical device interference

- Some components in the product can emit electromagnetic fields. If the product operators or people in the nearby environment wear medical devices (such as cochlear implants, implanted pacemakers, and defibrillators), make sure to consult the physicians and medical device manufacturers for medical advice, such as determining whether a safe distance from the product is required.
- If you suspect that the product is interfering with your medical device, stop using the product immediately.

Installation and operation

Power supply

- Before powering on the product, make sure the electrical interfaces are dry and clean. Do NOT power on the product in a humid environment.
- Do NOT use damaged or out-of-spec cables or adapters.
- You are recommended to use only the cables and power adapters provided by Hesai. If you are to design, configure, or select the power supply system (including cables) for the product, make sure to comply with the electrical specifications in the product's user manual (refer to [Section 1.5 Specifications](#) and the Power Supply Requirements section if available); for technical support, please contact Hesai.
- Please check [Section 2.2 Electrical interface](#) and strictly follow the instructions on plugging/unplugging the connector. If abnormalities already exist (such as bent pins, broken cables, and loose threads), stop using the product and contact Hesai technical support.

Eye safety

The product is a Class 1 laser product. It satisfies the requirements of:

- IEC 60825-1:2014
- EN 60825-1:2014+A11:2021
- CONSUMER LASER PRODUCT EN 50689:2021
- 21 CFR 1040.10 and 1040.11 except for deviations (IEC 60825-1 Ed.3) pursuant to Laser Notice No.56, dated May 8, 2019.

CAUTION: Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION

- For maximum self-protection, it is strongly warned that users do NOT look into the transmitting laser through a magnifying product (microscope, eye loupe, magnifying glass, etc.).
- This product does not have a power switch. It starts operating once connected to power. During operation, the entire cover lens can be regarded as the product's laser emitting window; looking at the cover lens can be regarded as looking into transmitting laser.

Product enclosure

- Do NOT crush or puncture the product. If the product enclosure is broken, stop using it immediately and contact Hesai technical support.
- Certain product models contain high-speed rotating parts. To avoid potential injuries, do NOT operate the product if the enclosure is loose.
- If the product enclosure consists of fins or grooves, please wear gloves when handling the product. Applying too much pressure with your bare hands may cause cuts, bruises or other injuries.

Drops and burns

The product contains metal, glass, and plastic, as well as sensitive electronic components. If the product is dropped or burnt, stop using it immediately and contact Hesai technical support.

Cover lens



The location of the cover lens is illustrated in [Section 1 Introduction](#).

- Do NOT apply protective film, wax or any other substance on the cover lens.
- To keep the product's cover lens from fingerprints and other stains, do NOT touch the cover lens with bare hands. If the cover lens is already stained, please refer to the cleaning method in [Section 5 Maintenance](#).
- To prevent scratches, do NOT touch the product's cover lens with hard or sharp objects. If scratches already exist, stop using the product and contact Hesai technical support. Severe scratches may affect the quality of the product's point cloud data.

Mounting

- Before operating the product, make sure it is properly and securely mounted. The mounting should prevent the product from leaving its mounting position under external forces (such as collisions, high winds, and stone impacts).
- If the product is installed in a cavity designed as a wet zone, make sure that no water accumulates in the cavity.
- Before installing any exterior part, please ensure that each exterior part and its movable area do not overlap the Field of View (FOV) of the lidar.



The lidar's FOV is the spatial angular range bounded by the horizontal and vertical FOV ranges (see [Section 1.5 Specifications](#)); the distance to the origin of the lidar's coordinate system is not limited. For inquiries about the FOV, please contact Hesai technical support.

Hot surface

During operation or the time period after the operation, the product's enclosure can be hot.

- To prevent discomfort or even burns, do NOT touch the product's enclosure with your skin.
- To prevent fires, make sure to keep flammable materials away from the product's enclosure.

Certain product models support active heating of the cover lens to reduce the impact of ice and frost.

- While active heating is ON, the cover lens can be hot. To prevent discomfort or even burns, avoid direct skin contact with the cover lens.
- When the cover lens is free of ice and frost, you may turn off active heating.

Peripherals

The product may be used along with accessories and devices, such as suction cup mounts, extension cables, power supplies, network devices, GNSS/PTP devices, CAN transceivers, and cleaning equipment.

When selecting a peripheral, please refer to all relevant specifications in the product's user manual or contact Hesai technical support. Using out-of-spec or unsuitable devices may result in product damage or even personal injuries.

Firmware and software upgrading

Make sure to use only the upgrade files provided by Hesai. Make sure to observe all the instructions provided for that upgrade file.

Customized firmware and software

- Before using a customized version of firmware and software, please fully understand the differences in functions and performance between the customized version and the standard version.
- Make sure to strictly follow all the instructions and safety precautions provided for that customized version. If the product does not function as anticipated, stop using the product immediately and contact Hesai technical support.

Point cloud data processing

- Certain product models support one or more point cloud data processing functions, including but not limited to: Noise Filtering, Interstitial Points Filtering, Retro Multi-Reflection Filtering, and Nonlinear Reflectivity Mapping.
- These functions are configurable and are intended only to assist the user in extracting information from the point cloud data. Users are in full control of whether to use any of these functions. Moreover, users are responsible for analyzing the product's intended application scenarios and evaluating the risk of enabling one or more of these functions in combination.
- To learn about the supported functions of a product model, please contact Hesai technical support.

Repair

- Unless expressly agreed to in writing by Hesai, do NOT disassemble, repair, modify, or alter the product by yourself or through any third party. Such a breach:
 - can result in product damage (including but not limited to water resistance failure), property loss, and/or injuries;
 - shall constitute a breach of warranty.
- For more product repair issues, please contact Hesai or an authorized Hesai service provider.

1 Introduction

1.1 Applicability

This manual applies to the following versions:

Software	15.AF.B0.00.02.H or later
Firmware of Sensor	1.b.0006 or later
Firmware of Controller	2.b.0436 or later

1.2 Operating principle

Distance measurement: Time of Flight (ToF)

1. A laser diode emits a beam of ultrashort laser pulses onto the target object.
2. The laser pulses are reflected after hitting the target object. The returning beam is detected by an optical sensor.
3. Distance to the object can be accurately measured by calculating the time between laser emission and receipt.

$$d = \frac{ct}{2}$$

d: Distance

c: Speed of light

t: Travel time of the laser beam

1.3 Basic structure

The basic structure is shown in [Figure 1](#).

Multiple pairs of laser emitters and receivers are attached to a motor that rotates 360° horizontally.




Figure 1. Partial cross-sectional diagram




Figure 2. Coordinate system (axonometric view)




Figure 3. Lidar azimuthal position (top view)

The lidar's coordinate system is illustrated in [Figure 2](#).

- Z-axis is the axis of rotation.

The lidar's azimuthal position is defined in [Figure 3](#).

- By default, the lidar rotates clockwise in the top view.
- Y-axis corresponds to 0° .
- Each laser channel has an intrinsic azimuth offset. The horizontal center of the emitter-receiver array defines the lidar's azimuthal position.

For example, when the horizontal center passes the 90° position, the lidar is at the 90° position, and the azimuth of the corresponding data block in the Point Cloud Data Packet is 90° .

1.4 Channel distribution and coordinate systems

All channels are unevenly distributed, as illustrated in [Figure 4](#).

- The elevations indicated in [Figure 4](#) are projections onto the plane; for the design value of each channel's vertical angle in space, see [Appendix A Channel distribution data](#).
- Vertical resolution: See [Section 1.5 Specifications](#).




Figure 4. Channel vertical distribution

Each channel has an intrinsic angle offset, both horizontally and vertically. These angles are recorded in this lidar unit's angle correction file.

Angle correction file

- The file is usually provided when shipping.
- In case you need to obtain this file again, please do one of the following:
 - See the API Reference Manual.
 - Ask Hesai technical support or your sales representative.




Figure 5. Laser firing position and IMU coordinate system (unit: mm)

In [Figure 5](#):

- The origin of the lidar's coordinate system is marked as a red dot.
- At the 0° azimuthal position, the optical center (midpoint of the entrance pupil and exit pupil) is marked as a yellow dot.
 - The distance measurements and the elevation of each channel are relative to the optical center.
 - These can be converted to be measurements relative to the origin; see [Appendix D Optical center offset correction](#).
- The origin of the lidar's IMU coordinate system is marked as a green dot.
 - The IMU measurements are relative to the origin.
 - The origin is used for extrinsic calibration.

1.5 Specifications

SENSOR

Scanning method	Mechanical rotation
Number of channels	128
Instrumented range	0 to 60 m
Ranging capability	40 m (at 10% reflectivity, for all channels)
Ranging accuracy ①	±3 cm (typical)
Ranging precision ①	2 cm (typical)
Horizontal FOV	360°
Horizontal resolution ②	Approx. 0.4°
Vertical FOV ③	95° (-4.4° to 90.5°)
Vertical resolution	0.74° (average)
Frame rate	10/20 Hz
Return mode	Single return: First/Strongest/Last Dual return: Last and Strongest (default) / Last and First / First and Strongest

MECHANICAL/ELECTRICAL/OPERATIONAL

Wavelength	905 nm
Laser class	Class 1 Eye Safe
Ingress protection	IP6K7
Dimensions	Height: 73.05 mm Bottom: Φ62.50 mm

Rated voltage range ④	DC 9 to 32 V
Power consumption ⑤	9.5 W
Operating temperature ⑥	-20°C to 65°C
Storage temperature ⑥	-40°C to 85°C
Weight	<250 g

DATA I/O

Data transmission	Standard 100Base-TX
Measurements	Distance, azimuth angle, and reflectivity
Valid point rate ⑦	Single Return: 1 152 000 points/sec Dual Return: 2 304 000 points/sec
Point cloud data rate	Single Return: 41.15 Mbps Dual Return: 82.30 Mbps
Clock source	GNSS/PTP (1588v2, 802.1AS, 802.1AS Automotive)



Specifications are subject to change. Please refer to the latest version of this manual.

Notes to specifications

① Ranging accuracy and ranging precision

- May vary with range, temperature, and target reflectivity.
- Ranging accuracy: the average measurement error over multiple measurements taken under the same conditions
- Ranging precision: the standard deviation of multiple measurements taken under the same conditions

② Horizontal resolution

Equivalent horizontal resolution in space.

③ Vertical FOV

Vertical angles' projections onto the plane, not the ones in space.

④ Rated voltage range

The input voltage at the lidar's connector shall be within 9 to 32 V DC.

⑤ Power consumption

Typical value

- Not including accessories such as the connection box.
- Test conditions: 25°C ambient temperature, 10 Hz frame rate.
- The external power supply should be able to provide at least 2.6 A, 30 W.

⑥ Operating temperature and storage temperature

Both refer to ambient air temperature.

- During operation, the lidar's surface and internal temperatures may exceed the ambient air temperature.
- To obtain the real-time temperature headroom of an internal location, refer to Get Lidar Status (0x09) in the TCP API Reference Manual.
- Defined as the point cloud data points (number of returns) generated per second.
- In **Single Return Mode**:
 - Given: horizontal FOV (360°), horizontal resolution (0.4° at 10 Hz), number of channels (128), and frame rate (10 Hz).
 - At 10 Hz, each channel generates $360/0.4 = 900$ points per frame; all channels generate $900 \times 128 = 115\,200$ points per frame, and 1 152 000 points (10 frames) per second.
- In **Dual Return Mode**, the point rate is twice that in **Single Return Mode**.

⑦ Valid point rate

2 Setup

Before operating the lidar, strip away the protective cover on the cover lens.



The information in this section may be different for customized models. The mechanical drawings and data exclusively provided for customized models shall prevail.

2.1 Mechanical installation

2.1.1 Exterior dimensions




Figure 6. Right side view (unit: mm)

2.1.2 Recommended installation




Figure 8. Recommended installation

To maximize data integrity and ESD protection, chassis grounding is strongly recommended:

- Mount the lidar on a properly grounded metal bracket.
- Ensure reliable electrical continuity between the lidar enclosure, the mounting screws, and the bracket.

In installations where chassis grounding is impractical or impossible (e.g., battery-powered or airborne platforms), high-quality shielded twisted pair (STP) Ethernet cables with properly grounded connectors is a recommended alternative.

2.1.3 Notes on screw installation

Screw type

SEMS screws (with pre-attached flat washers and lock washers) are recommended. Property class should be at least 4.8.

Screw torque

The base material of the threaded holes is aluminum alloy instead of steel. Refer to the following table for the appropriate screw torque.

Thread size	Recommended screw torque
M2	0.2 to 0.3 Nm
M3	0.5 to 0.6 Nm
M4	1 to 1.5 Nm
M5	2 to 2.5 Nm
M6	3.5 to 4 Nm

Thread service life

- Ten times. (Each screwing counts as one time, so as each unscrewing.)
- If threadlocker is used, clean the threaded hole before each retightening. Avoid contact between the cover lens and the cleaner.

2.2 Electrical interface

The lidar uses a Signal Electronics M8 series connector (male socket, on the lidar).




Figure 9. Connector right side view (unit: mm)





Figure 10. Connector front view (unit: mm)

2.2.1 Pin description

See [Section 2.3.1 Ports](#).

Timing requirements of GNSS signals (PPS and NMEA)



Cycle of the PPS signal	$t_3 = 1 \text{ s} \pm 50 \mu\text{s}$ (rising edge to rising edge)
Pulse width of the PPS signal	$t_1 \geq 1 \text{ ms}$ Recommended range: 10 to 100 ms
Timing relationship	As indicated by the gray arrows, the NMEA signal: <ul style="list-style-type: none"> • Should start after the PPS rising edge of the current second. • Should end after the PPS falling edge of the current second. • Should end before the PPS rising edge of the next second; $t_2 \geq 100 \text{ ms}$.

2.2.2 Connector use

Connection	<ol style="list-style-type: none">1. Turn off the power source.2. Align the slot on the cable's plug with the protrusion of the lidar socket.3. Insert the plug straight into the socket until fully seated.4. Rotate the coupling nut clockwise to tighten it.5. Set a torque wrench to 0.4 Nm and further tighten the coupling nut.
Disconnection	<ol style="list-style-type: none">1. Turn off the power source.2. Rotate the coupling nut counterclockwise to loosen it.3. Hold the plug's shell and pull the plug straight from the socket (avoiding twisting or bending).




Figure 11. Connector use



- Before connection, check the pins on the socket and the holes on the plug. In case of bent pins or damaged holes, stop using the connector and contact technical support.
- To prevent breakdowns, turn off the power source before connection and disconnection.
- Do NOT attempt to force open a connection by pulling on the cables or by twisting the connectors in any way. Doing so can loosen the connectors' shells, or even damage the contacts.
- If a right-angle connector is used, the joint between the cable and the connector's overmolded part (see arrow in [Figure 12. 1-to-3 splitter cable \(unit: mm\)](#)) can only withstand a lateral force of less than 40 N.
- If the connector's shell is accidentally pulled off, stop using the connector and contact Hesai technical support. Do NOT attempt to assemble the connector's shell and cable collet; do NOT connect a connector without its shell. Doing so may damage the lidar's circuits.
- For further troubleshooting, please contact Hesai technical support or obtain work instructions from the connector manufacturer.

2.3 Cable

Users can connect the lidar directly.

- Outer diameter (OD) = 5.50 ± 0.20 mm
- Minimum bend radius: $5 \times OD$



The default cable length and CNN1 rotation angle are shown in the image. Should there be other agreements with specific users, the other agreements shall prevail.




Figure 12. 1-to-3 splitter cable (unit: mm)

2.3.1 Ports



Avoid touching the reserved wires or ports with bare hands.

Port	Pin number	Wire color	Signal	Wire gauge	Wire color	Pin number	Port	Description
Lidar port CNN1	6	Red	Power	26 AWG	Blue	1	Power port CNN2	9 to 32 V
	1	Black	GND	26 AWG	Black	2		0 V
						-	GNSS CNN3	Ground for external GNSS module
	8	White	GNSS PPS	28 AWG	Blue	-		PPS synchronization signal 3.3 V, rising edge ≤ 500 ns, recommended pulse width ≥ 1 ms Cycle: 1 s (from rising edge to rising edge)
	7	Green	GNSS NMEA	28 AWG	Brown	-		Receiving serial data from the external GNSS module RS232 level, -13 to 13 V
	4	Yellow	Ethernet TX+	28 AWG	Orange white	1	Standard Ethernet port CNN4	-1 to 1 V
	5	Blue	Ethernet TX-	28 AWG	Orange	2		
	3	Orange	Ethernet RX+	28 AWG	Blue white	3		
2	Purple	Ethernet RX-	28 AWG	Blue	6			



Supported GNSS NMEA sentences: GPRMC, GNRMC

2.4 Network settings on the host computer

The lidar has no power switch. It starts transmitting data when both of these conditions are met:



- The lidar is connected to power.
- The lidar is connected to a host computer via Ethernet.

To analyze point cloud data, configure the network parameters of the host computer:



Network parameters	Value	Description
IP address	192.168.1.X	X can be selected from 2 to 200 and from 202 to 254.
Subnet mask	255.255.255.0	-
VLAN ID	Range: 1 to 4094	Required only when VLAN tagging is used. Make sure the host computer and the lidar use the same VLAN ID.

2.4.1 In Windows

1. [**Control Panel**] > [**Network and Internet**] > [**Network and Sharing Center**] > [**Change adapter settings**].
2. Right-click [**Ethernet**] or [**Ethernet X**] which shows Ethernet connection (with no red cross at the bottom left of the icon) > Select [**Properties**].



3. Double-click [**Internet Protocol Version 4 (TCP/IPv4)**].
4. Select [**Use the following IP addresses**] > Input the host computers's IP address and subnet mask.




Ping command can be used to check the connection:



1. Press Win + R to open the Run dialog box.
2. Enter "cmd" and click [**OK**] to open the Command Prompt.
3. Enter "ping 192.168.1.201" and check the output.

5. To enable VLAN tagging:

Click [**Configure**] > Under the [**Advanced**] tag, select [**VLAN ID**] from the [**Property**] list > Input a VLAN ID in the [**Value**] box > Click [**OK**].



If the [**Property**] list has no [**VLAN ID**], it is recommended to update the network adapter driver.

2.4.2 In Ubuntu

1. Find the host computer's network interface name.

Method 1

- a. Open **Settings — Network**.
- b. Look for the interface whose status is "Connected".
The name in parentheses after "Ethernet" is the network interface name.



Method 2

- a. Open a terminal and run this command:

```
ifconfig
```

- b. Look for the interface with non-zero RX packets and bytes.
(In the example below, **enp5s0** shows non-zero Rx packets and bytes, indicating active data transmission.)

```
> ifconfig
docker0: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
  inet [REDACTED] netmask [REDACTED] broadcast [REDACTED]
  ether [REDACTED] txqueuelen 0 (Ethernet)
  RX packets 0 bytes 0 (0.0 B)
  RX errors 0 dropped 0 overruns 0 frame 0
  TX packets 0 bytes 0 (0.0 B)
  TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

enp2s0f0: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
  ether [REDACTED] txqueuelen 1000 (Ethernet)
  RX packets 0 bytes 0 (0.0 B)
  RX errors 0 dropped 0 overruns 0 frame 0
  TX packets 0 bytes 0 (0.0 B)
  TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0

enp5s0: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
  ether [REDACTED] txqueuelen 1000 (Ethernet)
  RX packets 267706980 bytes 300970909734 (300.9 GB)
  RX errors 0 dropped 0 overruns 0 frame 0
  TX packets 3184 bytes 590575 (590.5 KB)
  TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

When not using VLAN

2. Run this command in the terminal:

```
sudo ifconfig ${interface_name} ${ip_addr}
```

- Replace `${interface_name}` with the host computer's network interface name.
- Replace `${ip_addr}` with the host computer's IP address.

When using VLAN

2. Run this command in the terminal:

```
sudo ip link add link ${interface_name} name ${interface_name}.${vlan_id} type vlan id ${vlan_id}
sudo ip link set up ${interface_name}.${vlan_id}
sudo ip addr add ${ip_addr}/24 dev ${interface_name}.${vlan_id}
ip addr show ${interface_name}.${vlan_id}
```


- Replace `${interface_name}` with the host computer's network interface name.
- Replace `${vlan_id}` with the host computer's VLAN ID.
- Replace `${ip_addr}` with the host computer's IP address.

2.5 Tools

Tool	Purpose	Where to find it
PandarView 2	Point cloud visualization software: To record and display point cloud data.	Download it at: https://www.hesaitech.com/downloads/
Pandar TCP Commands (PTC) API	To set parameters, check device info and status, or upgrade firmware and software. <div style="border: 1px dashed gray; padding: 5px; margin: 10px 0;"> <p style="text-align: center;">Network parameters:</p> <ul style="list-style-type: none"> • Default Source IPv4 address: 192.168.1.201 • Default PTC port: 9347 </div>	Contact Hesai technical support to receive the API Reference Manuals.
LidarUtilities	Software for host computers: To set parameters, check device info and status, or upgrade firmware and software.	Download it at: https://www.hesaitech.com/downloads/
Software development kits (SDKs) and ROS drivers	To assist development.	Visit Hesai's official GitHub page: https://github.com/HesaiTechnology

3 Data structure

Unless otherwise specified, all the multi-byte fields are unsigned values in little-endian format.



1. Network monitoring software (such as WireShark) usually does not display the **Ethernet tail** (4 bytes).

Figure 13. Data structure



The data format of the Fault Message Packet is described in the Diagnostic Manual. Please contact Hesai technical support for more information.

3.1 Point Cloud Data Packet

3.1.1 Ethernet Header

Point Cloud Data Packet: Ethernet Header

Field	Byte(s)	Description
Ethernet II MAC	12	Destination MAC: xx:xx:xx:xx:xx:xx (FF:FF:FF:FF:FF:FF for broadcast) Source MAC: xx:xx:xx:xx:xx:xx
Ethernet Data Packet Type	2	0x08, 0x00
Internet Protocol	20	Protocol parameters
UDP Port Number	4	Source port (default: 10000) Destination port (default: 2368)
UDP Length	2	Eight bytes more than point cloud UDP data (see Figure 13. Data structure).
UDP Checksum	2	Checksum of the Ethernet Header

3.1.2 Point cloud UDP data

Pre-Header

Field	Byte(s)	Description
Start of Packet	1	0xEE
Start of Packet	1	0xFF
Protocol Version Major	1	Main class of the point cloud UDP packet structure Current value: 0x01
Protocol Version Minor	1	Subclass of the point cloud UDP packet structure Current value: 0x04
Reserved	2	-

Header

Field	Byte(s)	Description
Channel Num	1	Fixed: 0x80 (128)
Block Num	1	Fixed: 0x02 (2)
Reserved	1	-
Dis Unit	1	Fixed: 0x04 (4 mm)
Return Num	1	Number of returns that each channel generates One return: 0x01 (1) Two returns: 0x02 (2)

Field	Byte(s)	Description	
Flags	1	Each bit indicates whether this data packet contains certain information.	
		Bit	Description
		[7:6] Reserved	-
		[5] Confidence	1 — YES 0 — NO
		[4:2] Reserved	-
		[1] IMU	1 — YES (fixed) 0 — NO
		[0] UDP Sequence	1 — YES (fixed) 0 — NO

Body

Return mode

The available return mode(s) are listed in the **Return Mode** field in [Section 3.1.2.4 Tail](#).

In Single Return mode, the measurements of each round of firing are stored in one block.

In Dual Return mode, the measurements of each round of firing are stored in two adjacent blocks (see table below), and the **Azimuth** fields of these two blocks are the same.

Return mode	Odd-numbered block	Even-numbered block	Note
Last and Strongest	Last return	Strongest return	If the last return is also the strongest, then the even-numbered block stores the second strongest return.
Last and First	Last return	First return	If there is only one return, then the two blocks store the same data.
First and Strongest	First return	Strongest return	If the first return is also the strongest, then the even-numbered block stores the second strongest return.

Field	Byte(s)	Description
Azimuth 1	2	For Block 1: Current reference angle of the azimuth Unit: 0.01°
Block 1	512	Measurements made by each channel (starting from Channel 1) Refer to Each block in the Body .
Azimuth 2	2	For Block 2: Current reference angle of the azimuth Unit: 0.01°
Block 2	512	Measurements made by each channel (starting from Channel 1) Refer to Each block in the Body .

Field	Byte(s)	Description
CRC	4	CRC-32/MPEG-2 checksum of the Body  For more on the CRC-32/MPEG-2 computation algorithm, refer to: https://www.mathworks.com/matlabcentral/fileexchange/72226-crc-32-mpeg-2-computation-algorithm

Each block in the Body

Field	Byte(s)	Description												
Channel 1	4	Measurements of Channel 1												
		<table border="1"> <thead> <tr> <th>Field</th> <th>Byte(s)</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Distance</td> <td>2</td> <td>Object distance = Distance × Dis Unit <div style="border: 1px dashed gray; border-radius: 10px; padding: 5px; display: inline-block;">  Dis Unit is specified in Section 3.1.2.2 Header. </div> </td> </tr> <tr> <td>Reflectivity</td> <td>1</td> <td>Range: 0 to 255 0 to 255 linearly represents target reflectivity 0 to 255%. Reflectivity = Reflectivity Field × 1%</td> </tr> <tr> <td>Confidence</td> <td>1</td> <td>This field is added only when bit[5] = 1 in the Flags field of the Header. <div style="border: 1px dashed gray; border-radius: 10px; padding: 5px; display: inline-block;">  This field is shown as "WeightFactor" in PandarView 2. </div> [7:6] Cover Lens Contamination Level <ul style="list-style-type: none"> • Range: 0 to 3 • Higher value indicates more contamination. [5:0] Discrete noise point level <ul style="list-style-type: none"> • Range: 0 to 63 • The higher the value, the more likely this data point is a discrete noise point (e.g., rain, fog, dust, or exhaust fumes). </td> </tr> </tbody> </table>	Field	Byte(s)	Description	Distance	2	Object distance = Distance × Dis Unit <div style="border: 1px dashed gray; border-radius: 10px; padding: 5px; display: inline-block;">  Dis Unit is specified in Section 3.1.2.2 Header. </div>	Reflectivity	1	Range: 0 to 255 0 to 255 linearly represents target reflectivity 0 to 255%. Reflectivity = Reflectivity Field × 1%	Confidence	1	This field is added only when bit[5] = 1 in the Flags field of the Header . <div style="border: 1px dashed gray; border-radius: 10px; padding: 5px; display: inline-block;">  This field is shown as "WeightFactor" in PandarView 2. </div> [7:6] Cover Lens Contamination Level <ul style="list-style-type: none"> • Range: 0 to 3 • Higher value indicates more contamination. [5:0] Discrete noise point level <ul style="list-style-type: none"> • Range: 0 to 63 • The higher the value, the more likely this data point is a discrete noise point (e.g., rain, fog, dust, or exhaust fumes).
		Field	Byte(s)	Description										
		Distance	2	Object distance = Distance × Dis Unit <div style="border: 1px dashed gray; border-radius: 10px; padding: 5px; display: inline-block;">  Dis Unit is specified in Section 3.1.2.2 Header. </div>										
Reflectivity	1	Range: 0 to 255 0 to 255 linearly represents target reflectivity 0 to 255%. Reflectivity = Reflectivity Field × 1%												
Confidence	1	This field is added only when bit[5] = 1 in the Flags field of the Header . <div style="border: 1px dashed gray; border-radius: 10px; padding: 5px; display: inline-block;">  This field is shown as "WeightFactor" in PandarView 2. </div> [7:6] Cover Lens Contamination Level <ul style="list-style-type: none"> • Range: 0 to 3 • Higher value indicates more contamination. [5:0] Discrete noise point level <ul style="list-style-type: none"> • Range: 0 to 63 • The higher the value, the more likely this data point is a discrete noise point (e.g., rain, fog, dust, or exhaust fumes). 												
Reflectivity	1	Range: 0 to 255 0 to 255 linearly represents target reflectivity 0 to 255%. Reflectivity = Reflectivity Field × 1%												
Confidence	1	This field is added only when bit[5] = 1 in the Flags field of the Header . <div style="border: 1px dashed gray; border-radius: 10px; padding: 5px; display: inline-block;">  This field is shown as "WeightFactor" in PandarView 2. </div> [7:6] Cover Lens Contamination Level <ul style="list-style-type: none"> • Range: 0 to 3 • Higher value indicates more contamination. [5:0] Discrete noise point level <ul style="list-style-type: none"> • Range: 0 to 63 • The higher the value, the more likely this data point is a discrete noise point (e.g., rain, fog, dust, or exhaust fumes). 												
Channel 2	4	Measurements of Channel 2												
...												
Channel 128	4	Measurements of Channel 128												

Tail

Field	Byte(s)	Description														
Reserved	11	-														
Working Mode	1	1 – Standby 0 – In operation														
Return Mode	1	0x33 – First 0x37 – Strongest 0x38 – Last 0x39 – Last and Strongest (default) 0x3B – Last and First 0x3C – First and Strongest														
Motor Speed	2	Unit: 0.1 RPM <div style="border: 1px dashed gray; border-radius: 10px; padding: 5px; display: inline-block;">  Spin rate of the motor (RPM) = frame rate (Hz) × 60 </div>														
Date & Time	6	Whole second part of the Coordinated Universal Time (UTC) of this data packet <table border="1" style="margin-top: 10px; width: 100%;"> <thead> <tr> <th>Each byte</th> <th>Range (decimal)</th> </tr> </thead> <tbody> <tr> <td>Year (current year minus 1900)</td> <td>≥70</td> </tr> <tr> <td>Month</td> <td>1 to 12</td> </tr> <tr> <td>Day</td> <td>1 to 31</td> </tr> <tr> <td>Hour</td> <td>0 to 23</td> </tr> <tr> <td>Minute</td> <td>0 to 59</td> </tr> <tr> <td>Second</td> <td>0 to 59</td> </tr> </tbody> </table>	Each byte	Range (decimal)	Year (current year minus 1900)	≥70	Month	1 to 12	Day	1 to 31	Hour	0 to 23	Minute	0 to 59	Second	0 to 59
Each byte	Range (decimal)															
Year (current year minus 1900)	≥70															
Month	1 to 12															
Day	1 to 31															
Hour	0 to 23															
Minute	0 to 59															
Second	0 to 59															

Field	Byte(s)	Description
UTC Fractional Seconds	4	The microsecond part of the Coordinated Universal Time (UTC) of this data packet. Unit: μs Range: 0 to 999 999 μs (1 s)
Factory Information	1	Fixed: 0x42
UDP Sequence	4	Sequence number of this data packet Range: 0 to 0xFF FF FF FF
IMU Temperature	2	Temperature provided by the inertial measurement unit (IMU), as a signed integer. Unit: 0.01°C
IMU Acceleration Unit	2	Conversion factor of acceleration, as an unsigned integer Currently 0x7A (122) Unit of acceleration: $0.001\text{ mg} \times 122 = 0.122\text{ mg}$ (g : standard gravity)
IMU Angular Velocity Unit	2	Conversion factor of angular velocity, as an unsigned integer Currently 0xBE9 (3049) Unit of angular velocity: $0.01\text{ mdps} \times 3049 = 30.49\text{ mdps}$ (millidegree per second)
Reserved	4	-

Field	Byte(s)	Description										
IMU X Axis Acceleration	2	Acceleration of the X-axis, measured by the IMU										
		<table border="1"> <tr> <td>Data type</td> <td>Signed integer</td> </tr> <tr> <td>Measurement range</td> <td> <ul style="list-style-type: none"> • $\pm 2 g$ • $\pm 4 g$ (default) • $\pm 8 g$ • $\pm 16 g$ </td> </tr> <tr> <td colspan="2"> <div style="border: 1px dashed gray; padding: 5px; display: flex; align-items: center;">  Use the PTC command (command code: 0xFF, 0x0000012E) to set the measurement range; see TCP API reference manual. </div> </td> </tr> <tr> <td>Unit of acceleration</td> <td>See the IMU Acceleration Unit field; currently $0.122 mg$.</td> </tr> <tr> <td>Example</td> <td>When this field is 5, X-axis acceleration = $5 \times 0.122 mg = 0.61 mg$.</td> </tr> </table>	Data type	Signed integer	Measurement range	<ul style="list-style-type: none"> • $\pm 2 g$ • $\pm 4 g$ (default) • $\pm 8 g$ • $\pm 16 g$ 	<div style="border: 1px dashed gray; padding: 5px; display: flex; align-items: center;">  Use the PTC command (command code: 0xFF, 0x0000012E) to set the measurement range; see TCP API reference manual. </div>		Unit of acceleration	See the IMU Acceleration Unit field; currently $0.122 mg$.	Example	When this field is 5, X-axis acceleration = $5 \times 0.122 mg = 0.61 mg$.
		Data type	Signed integer									
		Measurement range	<ul style="list-style-type: none"> • $\pm 2 g$ • $\pm 4 g$ (default) • $\pm 8 g$ • $\pm 16 g$ 									
		<div style="border: 1px dashed gray; padding: 5px; display: flex; align-items: center;">  Use the PTC command (command code: 0xFF, 0x0000012E) to set the measurement range; see TCP API reference manual. </div>										
Unit of acceleration	See the IMU Acceleration Unit field; currently $0.122 mg$.											
Example	When this field is 5, X-axis acceleration = $5 \times 0.122 mg = 0.61 mg$.											
Unit of acceleration	See the IMU Acceleration Unit field; currently $0.122 mg$.											
Example	When this field is 5, X-axis acceleration = $5 \times 0.122 mg = 0.61 mg$.											
IMU Y Axis Acceleration	2	Acceleration of the Y-axis										
IMU Z Axis Acceleration	2	Acceleration of the Z-axis										

Field	Byte(s)	Description	
IMU X Axis Angular Velocity	2	Angular velocity of the X-axis, measured by the IMU	
		Data type	Signed integer
		Measurement range	Unit: dps <ul style="list-style-type: none"> • ± 125 • ± 1000 (default) • ± 2000 <div style="border: 1px dashed gray; padding: 5px; margin-top: 10px;">  Use the PTC command (command code: 0xFF, 0x0000012E) to set the measurement range; see TCP API reference manual. </div>
		Unit of angular velocity	See the IMU Angular Velocity Unit field; currently 30.49 mdps.
		Example	When this field is 5, X-axis angular velocity = 5×30.49 mdps = 152.45 mdps.
IMU Y Axis Angular Velocity	2	Angular velocity of the Y-axis	
IMU Z Axis Angular Velocity	2	Angular velocity of the Z-axis	
CRC	4	CRC-32/MPEG-2 checksum of the Tail	

3.1.3 Ethernet tail

Field	Byte(s)	Description
FCS	4	Frame check sequence

3.1.4 Point cloud data analysis method

Take **Channel 6** in **Block 1** as an example.

Analyze the vertical angle of a data point

The designed vertical angle of **Channel 6** is 0.13° , according to [Appendix A Channel distribution data](#).



- The accurate vertical angles are recorded in the angle correction file of this lidar; see [Angle correction file](#).
- 0° is the horizontal direction. The upward direction is defined as positive; see [Figure 4. Channel vertical distribution](#).

Analyze the horizontal angle of a data point



Y-axis is the 0° position. The clockwise direction (in the top view) is defined as positive; see [Figure 3. Lidar azimuthal position \(top view\)](#).

$$\text{Horizontal angle} = \textcircled{1} + \textcircled{2}$$

- ① Angular position at the start time (see [Section B.3 Start time of each block](#)) of the current block
- ② Firing time angular offset of the current firing channel

$$\textcircled{1} = \textcircled{3} + \textcircled{4}$$

- ③ Current reference azimuth of this block
Can be read from the **Azimuth 1** field. See [Section 3.1.2.3 Body](#).
- ④ Horizontal angle offset of the current firing channel
The offset of **Channel 6** is -9.72° , according to [Appendix A Channel distribution data](#).



The accurate horizontal angle offsets are recorded in this lidar unit's angle correction file; see [Angle correction file](#).

$$\textcircled{2} = \textcircled{5} \times \textcircled{6}$$

- ⑤ Firing time offset of the current firing channel
See [Section B.4 Laser firing time of each channel](#).
- ⑥ Spin rate of the motor
See the **Motor Speed** field in [Section 3.1.2.4 Tail](#). The unit should be converted to °/s.

Integration note for accuracy-critical applications

The lidar follows an **interleaved, unevenly spaced** firing sequence:

- The channel index does NOT represent the firing time order.
- The firing time intervals between channels are NOT uniform.

In accuracy-critical applications, the firing time offsets in [Section B.4](#) SHALL be applied for motion compensation (i.e., deskewing).

False assumptions (such as a linear firing sequence or uniform time spacing) can lead to erroneous point timestamps and degraded motion compensation, especially during high-speed motion. As a result, gaps or ghosting artifacts may appear on vertical structures (e.g., walls and pipes) in the point cloud.


An application may be considered accuracy-critical if it meets one or more of these conditions:

- Used in surveying and mapping
- Deployed on a mobile platform, such as a vehicle, drone, or robot
- Implements motion compensation algorithms or SLAM/mapping stacks

Analyze the distance of a data point

See the **Distance** field of **Block 1: Channel 6** in [Section 3.1.2.3 Body](#).

Draw the data point in a spherical or rectangular coordinate system



Obtain the real-time point cloud data by analyzing and drawing every data point in each frame

4 Parameter interfaces

All the parameters in this section can be accessed using API; some of the parameters are also shown in LidarUtilities.



Users cannot read or write the parameters in this section.

4.1 Network connection

4.1.1 Source

Source IPv4 Address

Option(s)	Description
Default: 192.168.1.201	UDP
Default: 192.168.1.201	PTC API

Source IPv4 Subnet Mask

Option(s)	Description
Default: 255.255.255.0	Applies to both UDP and PTC ports.

Source IPv4 Gateway

Option(s)	Description
Default: 192.168.1.1	Applies to both UDP and PTC ports.

4.1.2 Destination

Destination IPv4 Address

Option(s)	Description
255.255.255.255	Destination address for Point Cloud Data Packets

Destination Point Cloud UDP Port

Option(s)	Description
Default: 2368	Destination port for Point Cloud Data Packets

Destination Fault Message Port

Option(s)	Description
Default: 2369	Destination port for Fault Message Packets

4.2 Functional settings

Azimuth FOV

Options	Description
Single-Section FOV (default) Multi-Section FOV	<p>Configuration mode of the azimuth FOV</p> <p>The lidar outputs valid data only within the specified azimuth FOV ranges.</p> <ul style="list-style-type: none"> • In Single-Section FOV mode, one continuous angle range [Start Angle, End Angle] is specified for all channels. • In Multi-Section FOV mode, multiple (1 to 5) continuous angle ranges are specified for all channels. <div style="border: 1px dashed gray; padding: 10px; margin-top: 10px;"> <ul style="list-style-type: none"> • The angles in degrees are accurate to the first decimal place. • The Start Angle and the End Angle must be different. • When the Start Angle is larger than the End Angle: <ul style="list-style-type: none"> ◦ The Start Angle must not be 360°. ◦ The End Angle must not be 0°. ◦ The actual range is the union of [Start Angle, 360°) and [0°, End Angle). <p>For instance, when the angle range is set to be [270°, 90°), the actual azimuth FOV is [270°, 360°) ∪ [0°, 90°).</p> </div>

Return Mode

Option(s)	Description
Single Return: <ul style="list-style-type: none"> • Strongest • Last • First Dual Return: <ul style="list-style-type: none"> • Last and Strongest (default) • Last and First • First and Strongest 	The current return mode is shown in Point Cloud Data Packets; see the Return Mode field in Section 3.1.2.4 Tail .

Spin Rate

Option(s)	Description
600 RPM (default)	Spin rate of the motor
1200 RPM	The current spin rate is shown in Point Cloud Data Packets; see the Motor Speed field in Section 3.1.2.4 Tail .

Sync Angle

Option(s)	Description
[0°, 360°)	<p data-bbox="645 277 792 309">Sync angle</p> <p data-bbox="645 352 1514 384">At every full second, the lidar will rotate to that azimuthal position.</p> <div data-bbox="651 403 2074 469" style="border: 1px dashed gray; padding: 5px;"> <p data-bbox="667 411 1615 453"> Lidar azimuthal position is defined in Section 1.3 Basic structure.</p> </div> <div data-bbox="651 499 2074 791" style="border: 1px dashed gray; padding: 5px;"> <p data-bbox="770 515 1771 547">Definition of the full second (detailed in Section B.1 Source of absolute time):</p> <ul data-bbox="779 571 2018 772" style="list-style-type: none"> <li data-bbox="779 571 1966 603">• When GNSS is locked, the full second is defined as the rising edge of the GNSS PPS signal. <li data-bbox="779 611 2018 691">• When PTP is tracking or locked, the full second is retrieved from the PTP signal. (PPS signal is not required nor used.) <li data-bbox="779 699 1973 772">• When PTP is frozen or in free run, the full second is defined as the rising edge of the lidar's internal 1 Hz signal. </div> <p data-bbox="645 826 2074 900">To phase-lock multiple lidar units, connect them to the same clock source and set the same sync angle. These lidar units will rotate to the same azimuthal position at every full second.</p>

Trigger Method

Option(s)	Description				
Angle-Based (default) Time-Based	The way laser firings are triggered <table border="1" data-bbox="645 328 2074 488"> <tbody> <tr> <td>Angle-Based</td> <td>Lasers fire every 0.4° at 10 Hz. Lasers fire every 0.8° at 20 Hz.</td> </tr> <tr> <td>Time-Based</td> <td>Lasers fire every 111.111 μs.</td> </tr> </tbody> </table>	Angle-Based	Lasers fire every 0.4° at 10 Hz. Lasers fire every 0.8° at 20 Hz.	Time-Based	Lasers fire every 111.111 μs.
Angle-Based	Lasers fire every 0.4° at 10 Hz. Lasers fire every 0.8° at 20 Hz.				
Time-Based	Lasers fire every 111.111 μs.				

4.3 State settings**Reset All Settings**

Option(s)	Description
Reset All Settings	Reset all the parameters in Section 4.2 Functional settings to factory defaults.

Restart

Option(s)	Description
N/A	Afterward, the Start-Up Times in Section 4.6 Operation Statistics increments by 1.

Standby Mode

Option(s)	Description
In Operation (default) Standby	In Standby mode, the motor stops running and lasers stop firing.

4.4 Time sync

Read-only parameter	Description	
PTP Status	Free Run	No PTP master is selected.
	Tracking	Attempting to sync with the selected PTP master, but the absolute offset exceeds the user-specified limit; see PTP Lock Time Offset in this section.
	Locked	The absolute offset is within the user-specified limit.
	Frozen	The lidar has lost connection to the PTP master and is attempting to recover it. Meanwhile, lidar time will drift from the last synchronized time.

Clock Source

Option(s)	Description
GNSS PTP (default)	External source of absolute time

PTP Profile

Option(s)	Description
1588v2 (default) 802.1AS 802.1AS Automotive	IEEE timing and synchronization standard

PTP Lock Time Offset

Option(s)	Description
1 to 1000 μ s (integer) Default: 100	Upper limit of the absolute offset between Slave and Master when the lidar is in PTP Locked status; see PTP Status .

PTP Domain Number

Option(s)	Description
0 to 127 (integer) Default: 0	Domain attribute of the local clock

PTP Network Transport

Option(s)	Description
L2 UDP/IP (default)	Network transport protocol

4.5 Lidar info

Read-only parameter	Description
SN	Serial Number
PN	Part Number, indicating the lidar's hardware version Format: [Lidar Model]-[Configuration]
MAC address	Media access control (MAC) address Format: XX:XX:XX:XX:XX:XX (hexadecimal)

Angle correction file

Option(s)	Description
Get File	The angle correction file of each lidar unit is used to correct the azimuth and elevation of each channel.

4.6 Operation Statistics

Availability

- Start-Up Times
- System Uptime
- Total Operation Time

4.7 Upgrade

Upgrade

Option(s)	Description
Upgrade	Upgrade the lidar's firmware and software.

5 Maintenance

The lidar's cover lens is made of plastic (polycarbonate, PC).

- Do NOT wipe the cover lens when it is dry, nor use abrasive cleaners. Doing so can damage the optical coating.
- Do NOT use organic cleaners, which can damage the cover lens and even cause cracking.
 - Organic cleaners include but are not limited to tar removers, self-cleaning agents, adhesive removers, coating removers, foam cleaners, iron powder removers for car paint, glass cleaners, thinning agents, de-icers, paint surface treatment agents, alcohol, and vinegar.
 - If organic cleaners may be present when cleaning the equipment or performing related operations, please protect the cover lens to prevent any contact with organic cleaners.
- Do NOT apply excessive force to the lidar, as this can damage the cover lens.
 - Using automatic cleaning devices that are not specifically designed for lidars may pose risks. Please contact Hesai technical support for assessment.
 - Do NOT use sharp objects (such as knives or metal tweezers) or hard brushes (such as stiff nylon brushes or wire brushes) to scratch the cover lens cover surface. Such actions may damage the cover lens surface, and in severe cases, may cause malfunction.
- After prolonged exposure to strong sunlight and high temperatures, the cover lens should NOT be cleaned immediately.
- If snow or ice accumulates on the cover lens, do NOT use a pressure washer or ice scraper.
 - A small broom is recommended to remove snow.
 - A solvent-free (i.e., free of organic solvents) ice removal spray is recommended to remove ice; alternatively, wait for the ice to melt by itself.
- Do NOT wax the cover lens.



Please regularly check on the cover lens, considering your use frequency, storage environment, and climate conditions.



- If foreign objects (such as dust, fingerprints, or oil stains) are found on the cover lens, make sure to clean them.
- If corrosive foreign objects (such as insect remains, bird droppings, tree resin, road dust, industrial dust, asphalt, soot particles, and road salt) are found on the cover lens, make sure to clean them immediately.

Cleaning procedure

1. Make sure the lidar is powered OFF.
2. Choose an appropriate cleaning agent:
 - For light stains, use room temperature water.
 - For heavier stains, use a mild soap solution (no more than two tablespoons of soap per quart or liter of water).
 - For stubborn stains, use a solvent-free (i.e., free of organic solvents), pH-neutral detergent at room temperature, such as car shampoo.
3. Take a clean soft sponge or anti-static microfiber cloth, dampen it with the chosen cleaning agent, and gently wipe the dirty area on the cover lens back and forth.
4. For stubborn stains, cover the dirty area with the dampened sponge or cloth to soften the stains before wiping.
5. Immediately after removing the stains, rinse the cover lens with clean water. Then, use a clean soft sponge or microfiber cloth to gently wipe away any remaining liquid (which may contain residual cleaning agents or contaminants).

6 Troubleshooting

If the following procedures cannot solve your problem, please contact Hesai technical support.

Symptoms	Points to check
Motor is not running.	<p>Make sure that the following conditions are met:</p> <ul style="list-style-type: none"> • The power adapter is properly connected and in good condition. • The input voltage and input current satisfy the requirements in Section 1.5 Specifications. • The lidar can be accessed using LidarUtilities (see Cannot connect to lu). • The lidar is not in standby mode; this can be confirmed using LidarUtilities or PTC commands. <p>Afterward, power on the lidar again and check if the symptom persists.</p>
Motor is running, but no output data is received, neither by Wireshark nor by PandarView 2.	<p>Make sure that the following conditions are met:</p> <ul style="list-style-type: none"> • The Ethernet cable is properly connected (by unplugging and plugging again). • Destination IP is correctly set; this can be confirmed using LidarUtilities or PTC commands. • Firmware version is correct; this can be confirmed using LidarUtilities or PTC commands. • The lidar is emitting laser light; this can be confirmed using an infrared camera, an infrared sensor card, or a phone camera without an infrared filter. <p>Afterward, power on the lidar again and check if the symptom persists.</p>
Output data can be received by Wireshark but not by PandarView 2.	<p>Make sure that the following conditions are met:</p> <ul style="list-style-type: none"> • Lidar Destination Port is correctly set; this can be confirmed using LidarUtilities or PTC commands. • If VLAN is enabled, the computer's VLAN ID should be the same as the lidar's; this can be checked using LidarUtilities or PTC commands. • The computer's firewall for public networks is turned off, or PandarView 2 is added to firewall exceptions. • The latest PandarView 2 is installed (see Downloads page of Hesai's official website or contact Hesai technical support). <p>Afterward, power on the lidar again and check if the symptom persists.</p>

Symptoms	Points to check
The lidar cannot connect to LidarUtilities.	<p>Make sure that the following conditions are met:</p> <ul style="list-style-type: none"> • Ethernet cable is properly connected (by unplugging and plugging again). • The lidar's IP is in the same subnet with the computer's (WireShark may be used to check the lidar's IP that broadcasts data packets). • If VLAN is enabled, the computer's VLAN ID should be the same as the lidar's; this can be checked using LidarUtilities or PTC commands. <p>Afterward, follow these steps:</p> <ol style="list-style-type: none"> 1. Restart the computer or connect the lidar to another computer. 2. Power on the lidar again and check if the symptom persists.
Point cloud is abnormal, showing obviously misaligned points, flashing points, or incomplete FOV.	<p>Make sure that the following conditions are met:</p> <ul style="list-style-type: none"> • The lidar's cover lens is clean. If not, refer to Section 5 Maintenance for the cleaning method. • The lidar's angle correction file is applied (refer to PandarView 2 User Manual). • Spin Rate is steady; this can be confirmed either by checking the Motor Speed field (if available) in Point Cloud Data Packets, or by using LidarUtilities, PandarView 2 or PTC commands. • The lidar's internal temperature is between -20°C and 95°C; this can be confirmed using LidarUtilities, PandarView 2 or PTC commands. <p>Afterward, check for packet loss.</p> <p>If no packet is lost yet the point cloud flashes, try these steps:</p> <ol style="list-style-type: none"> 1. Update PandarView 2 to the latest version (see Downloads page of Hesai's official website or contact Hesai technical support). 2. Restart the computer. <p>If the point cloud is still abnormal, try these steps:</p> <ol style="list-style-type: none"> 1. Connect the lidar to another computer and another network. 2. Power on again and check if the symptom persists.

Symptoms	Points to check
<p>The number of data packets received is abnormal, indicating missing packets.</p>	<p>Make sure that the following conditions are met:</p> <ul style="list-style-type: none"> • Spin Rate is steady; this can be confirmed either by checking the Motor Speed field (if available) in Point Cloud Data Packets, or by using LidarUtilities, PandarView 2 or PTC commands. • The lidar's internal temperature is between -20°C and 95°C; this can be confirmed using LidarUtilities, PandarView 2 or PTC commands. • Ethernet is not overloaded. • No switch is connected to the network (the data transmitted from other devices may cause network congestion and packet loss). <p>Afterward, follow these steps:</p> <ol style="list-style-type: none"> 1. Connect the computer to no other devices but the lidar and check for packet loss. 2. Power on the lidar again and check if the symptom persists.
<p>GNSS cannot be locked.</p>	<p>Make sure that the following conditions are met:</p> <ul style="list-style-type: none"> • GNSS receiver is properly connected. • PPS signal is connected to the lidar. • GNSS Destination Port is correctly set; this can be confirmed using LidarUtilities or PTC commands. • The GNSS signals satisfy the electrical requirements in Section 2.2 Electrical interface. <p>Afterward, power on the lidar again and check if the symptom persists.</p>

Appendix A: Channel distribution data

A.1 Angular position and performance

Notes to the table

- Angular position** Design values of each channel's horizontal (azimuth) angle offset and vertical (elevation) angle.
- The accurate values are recorded in this lidar unit's angle correction file.
 - To analyze point cloud data, refer to [Section 3.1.4 Point cloud data analysis method](#).
- Vertical angles** Angles in space.
For the projected angles onto the plane, see [Figure 4](#).

To improve measurement performance, only a subset of channels are enabled in the near field.



- When distance < 0.35 m, **63** channels are enabled.
 - The 60 odd-numbered channels within Channels 1 to 120
 - Channels 125, 127, and 128
- When $0.35 \text{ m} \leq \text{distance} < 0.5 \text{ m}$, **68** channels are enabled.
 - The 60 odd-numbered channels within Channels 1 to 120
 - Channels 121 to 128

Channel No.	Angular position (°)		Instrumented range (m)	
	Horiz. offset	Vertical	Min	Max
1	-1.08	-4.43	0.5	60
2	-9.71	-3.50	0	60
3	-1.09	-2.55	0.5	60
4	-9.71	-1.65	0	60

Channel No.	Angular position (°)		Instrumented range (m)	
	Horiz. offset	Vertical	Min	Max
5	-1.10	-0.75	0.5	60
6	-9.72	0.13	0	60
7	-1.12	0.99	0.5	60
8	-9.73	1.85	0	60
9	2.69	2.64	0.5	60
10	11.33	3.46	0	60
11	2.68	4.29	0.5	60
12	11.34	5.09	0	60
13	2.68	5.91	0.5	60
14	11.36	6.69	0	60
15	2.68	7.49	0.5	60
16	11.39	8.25	0	60
17	-1.19	9.08	0.5	60
18	-9.92	9.84	0	60
19	-1.21	10.59	0.5	60
20	-9.98	11.34	0	60
21	-1.22	12.08	0.5	60
22	-10.04	12.81	0	60
23	-1.24	13.54	0.5	60
24	-10.11	14.26	0	60

Channel No.	Angular position (°)		Instrumented range (m)	
	Horiz. offset	Vertical	Min	Max
25	2.50	15.11	0.5	60
26	11.47	15.83	0	60
27	2.51	16.53	0.5	60
28	11.56	17.23	0	60
29	2.52	17.93	0.5	60
30	11.65	18.62	0	60
31	2.54	19.31	0.5	60
32	11.75	19.99	0	60
33	-1.33	20.71	0.5	60
34	-10.60	21.38	0	60
35	-1.35	22.07	0.5	60
36	-10.71	22.73	0	60
37	-1.37	23.42	0.5	60
38	-10.84	24.07	0	60
39	-1.39	24.76	0.5	60
40	-10.97	25.40	0	60
41	2.64	26.06	0.5	60
42	12.39	26.73	0	60
43	2.67	27.39	0.5	60
44	12.55	28.05	0	60

Channel No.	Angular position (°)		Instrumented range (m)	
	Horiz. offset	Vertical	Min	Max
45	2.70	28.71	0.5	60
46	12.71	29.35	0	60
47	2.73	30.02	0.5	60
48	12.89	30.66	0	60
49	-1.51	31.37	0.5	60
50	-11.77	32.05	0	60
51	-1.54	32.68	0.5	60
52	-11.96	33.34	0	60
53	-1.57	33.99	0.5	60
54	-12.15	34.63	0	60
55	-1.60	35.29	0.5	60
56	-12.36	35.92	0	60
57	2.94	36.56	0.5	60
58	13.96	37.23	0	60
59	2.98	37.86	0.5	60
60	14.21	38.51	0	60
61	3.04	39.15	0.5	60
62	14.48	39.79	0	60
63	3.09	40.45	0.5	60
64	14.76	41.07	0	60

Channel No.	Angular position (°)		Instrumented range (m)	
	Horiz. offset	Vertical	Min	Max
65	-1.77	41.78	0.5	60
66	-13.62	42.47	0	60
67	-1.80	43.08	0.5	60
68	-13.91	43.75	0	60
69	-1.85	44.37	0.5	60
70	-14.22	45.02	0	60
71	-1.89	45.67	0.5	60
72	-14.55	46.29	0	60
73	3.44	46.93	0.5	60
74	16.55	47.65	0	60
75	3.53	48.23	0.5	60
76	16.98	48.91	0	60
77	3.62	49.53	0.5	60
78	17.43	50.18	0	60
79	3.72	50.82	0.5	60
80	17.92	51.44	0	60
81	-2.14	52.17	0.5	60
82	-16.65	52.84	0	60
83	-2.20	53.47	0.5	60
84	-17.16	54.11	0	60

Channel No.	Angular position (°)		Instrumented range (m)	
	Horiz. offset	Vertical	Min	Max
85	-2.26	54.78	0.5	60
86	-17.70	55.38	0	60
87	-2.33	56.09	0.5	60
88	-18.30	56.66	0	60
89	4.37	57.36	0.5	60
90	21.24	58.11	0	60
91	4.54	58.68	0.5	60
92	22.06	59.37	0	60
93	4.73	60.00	0.5	60
94	22.96	60.64	0	60
95	4.93	61.33	0.5	60
96	23.96	61.90	0	60
97	-2.77	62.71	0.5	60
98	-22.52	63.44	0	60
99	-2.88	64.06	0.5	60
100	-23.61	64.72	0	60
101	-3.01	65.41	0.5	60
102	-24.83	66.00	0	60
103	-3.15	66.78	0.5	60
104	-26.20	67.29	0	60

Channel No.	Angular position (°)		Instrumented range (m)	
	Horiz. offset	Vertical	Min	Max
105	6.43	68.10	0.5	60
106	32.52	69.12	0	60
107	6.87	69.49	0.5	60
108	34.78	70.36	0	60
109	7.39	70.89	0.5	60
110	37.40	71.58	0	60
111	8.01	72.32	0.5	60
112	40.46	72.77	0	60
113	-4.25	73.88	0.5	60
114	-41.40	75.22	0	60
115	-4.60	75.36	0.5	60
116	-45.72	76.40	0	60
117	-5.04	76.87	0.5	60
118	-50.95	77.51	0	60
119	-5.61	78.41	0.5	60
120	-57.28	78.51	0	60
121	26.63	79.62	0.35	60
122	31.42	81.04	0.35	60
123	38.15	82.40	0.35	60
124	47.90	83.64	0.35	60

Channel No.	Angular position (°)		Instrumented range (m)	
	Horiz. offset	Vertical	Min	Max
125	-6.32	85.36	0	60
126	-0.86	87.02	0.35	60
127	18.19	88.64	0	60
128	117.30	88.99	0	60

A.2 Angle correction file

Purpose

Each lidar unit has an angle correction file, which contains the horizontal angle offsets (azimuth offsets) and vertical angles (elevation). Such corrections are used for:

- Point cloud data analysis (see [Section 3.1.4 Point cloud data analysis method](#))
- Point cloud display in PandarView 2

How to obtain this file

Use one of these ways:

- Send PTC command 0x05; see the TCP API Reference Manual.
- Export the file using PandarView 2; see the PandarView 2 User Manual.
- Ask Hesai technical support or your sales representative.

Data format

The CSV file is as follows.



- The angles are in units of degrees.
- The last line is the SHA-256 checksum.

```

EEFF,1,1
Channel,Elevation,Azimuth
1,xxx,xxx
2,xxx,xxx
...
127,xxx,xxx
128,xxx,xxx
XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX

```

Description of Row 1

Field	Description
Beginning of File	Fixed: 0xEE FF
Protocol Version Major	Current value: 0x01
Protocol Version Minor	Current value: 0x01

Appendix B: Absolute time of point cloud data

B.1 Source of absolute time

The lidar retrieves the current absolute time by connecting to an external clock source.

B.1.1 GNSS as the clock source

The lidar connects to a third-party GNSS module to obtain pulse-per-second (PPS) signals and NMEA sentences.

- The timing requirements of PPS and NMEA are shown in [Section 2.2.1 Pin description](#).

The absolute time is updated as follows:

NMEA status	Date and time (accurate to the second)	Lidar behavior
Unlocked (Initial)	Virtual	Because the lidar has not been locked before, it starts counting from a virtual UTC (such as 2000-01-01 00:00:00) using the lidar's internal 1 Hz signal.
Locked	Synchronized	At each rising edge of the internal 1 Hz signal, the lidar obtains the actual date and time by performing these two steps: <ol style="list-style-type: none"> 1. Extract the date and time from the previous NMEA message. 2. Add 1 full second.
Unlocked (Lost)	Drifting	When the lidar goes from Locked to Unlocked, it starts counting from the last synchronized time using the lidar's internal 1 Hz signal. This absolute time will gradually drift from the actual GNSS time.

PPS status	μ s time	Lidar behavior
Unlocked (Initial)	Not synchronized	The lidar's internal 1 Hz signal is not aligned with the GNSS second.

PPS status	μ s time	Lidar behavior
Locked	Synchronized	The rising edge of the lidar's internal 1 Hz signal is aligned with the rising edge of the PPS signal (i.e. the start of each GNSS second).
Unlocked (Lost)	Drifting	The lidar counts the absolute time using the internal 1 Hz signal. This absolute time will gradually drift from the actual GNSS second.

B.1.2 PTP as the clock source

The lidar connects to a third-party PTP master to obtain PTP signal.



- PPS signal is not required nor used.
- PTP can be configured using LidarUtilities or PTC commands.
- The status of PTP signal can be found using LidarUtilities or PTC commands.
- The lidar does not output GNSS Data Packets.

The absolute time is updated as follows:

PTP status	Date and time (accurate to the microsecond)	Lidar behavior
Free run	Virtual	Because the lidar has not been locked before, it starts counting from a virtual UTC (such as 2000-01-01 00:00:00) using the lidar's internal 1 Hz signal.
Tracking or Locked	Synchronized	The lidar extracts the actual date and time from the PTP master's messages.
Frozen	Drifting	When the lidar goes from Tracking/Locked to Frozen, it starts counting from the last synchronized time using the lidar's internal 1 Hz signal. This absolute time will gradually drift from the actual PTP time.



- PTP is a Plug & Play protocol; the lidar works as a PTP slave device and requires no additional setup.
- The **UTC Fractional Seconds** and **Date & Time** fields in Point Cloud Data Packets strictly follow the PTP master device. Certain PTP

master devices may have a specified offset from the lidar's time output. Please verify the configuration and calibration of your PTP master device.

B.2 Absolute time of the Point Cloud Data Packets

The absolute time of a Point Cloud Data Packet is $t_0 = t_s + t_{ms}$, where:

- t_s is the whole second part (see the **Date & Time** field).
- t_{ms} is the microsecond or nanosecond part (see the **UTC Fractional Seconds** field).

The definition of the above fields is in [Section 3.1.2.4 Tail](#).

B.3 Start time of each block

Given the absolute time of this Point Cloud Data Packet as t_0 , the start time of each block $t(m)$ can be calculated.

At each $t(m)$, the lidar saves the current azimuth into the current block's Azimuth field in the Point Cloud Data Packet; see [Section 3.1.2.3 Body](#).

(Unit: μs)

Single Return mode

Block	Start time $t(m)$
Block 1	$t_0 - 111.111 - 1888$
Block 2	$t_0 - 1888$

Dual return mode

Block	Start time $t(m)$
Block 1 & Block 2	$t_0 - 1888$

B.4 Laser firing time of each channel

In Block m , the absolute firing time of Channel n is:

$$t(m, n) = t(m) + \Delta t(n)$$

Look up the firing time offsets $\Delta t(n)$ in the table below:

Firing time offsets (unit: μs)

Channel	Firing time offset						
1	95.18	2	23.24	3	98.22	4	20.2
5	101.26	6	17.16	7	104.3	8	14.12
9	77.28	10	92.14	11	74.24	12	89.1
13	71.2	14	86.06	15	68.16	16	83.02
17	50.26	18	11.08	19	47.22	20	8.04
21	44.18	22	5	23	41.14	24	1.96
25	65.12	26	105.82	27	62.08	28	102.78
29	59.04	30	99.74	31	56	32	96.7
33	38.1	34	24.76	35	35.06	36	21.72
37	32.02	38	18.68	39	28.98	40	15.64
41	78.8	42	93.66	43	75.76	44	90.62
45	72.72	46	87.58	47	69.68	48	84.54
49	51.78	50	12.6	51	48.74	52	9.56
53	45.7	54	6.52	55	42.66	56	3.48

B.4 Laser firing time of each channel

Channel	Firing time offset						
57	66.64	58	103.54	59	63.6	60	100.5
61	60.56	62	97.46	63	57.52	64	94.42
65	39.62	66	22.48	67	36.58	68	19.44
69	33.54	70	16.4	71	30.5	72	13.36
73	76.52	74	91.38	75	73.48	76	88.34
77	70.44	78	85.3	79	67.4	80	82.26
81	49.5	82	10.32	83	46.46	84	7.28
85	43.42	86	4.24	87	40.38	88	1.2
89	64.36	90	105.06	91	61.32	92	102.02
93	58.28	94	98.98	95	55.24	96	95.94
97	37.34	98	24	99	34.3	100	20.96
101	31.26	102	17.92	103	28.22	104	14.88
105	78.04	106	92.9	107	75	108	89.86
109	71.96	110	86.82	111	68.92	112	83.78
113	51.02	114	11.84	115	47.98	116	8.8
117	44.94	118	5.76	119	41.9	120	2.72
121	65.88	122	62.84	123	59.8	124	56.76
125	38.86	126	35.82	127	32.78	128	29.74

Appendix C: Power supply requirements

C.1 Input voltage

To ensure that the input voltage U_{in} at the lidar's connector (see [Section 2.2 Electrical interface](#)) is between 9 to 32 V DC, check these specifications:

- U_s : Voltage of the power source
- U_{drop} : Voltage drop over the cable, from the power source to the lidar's connector

$$U_{in} = U_s - U_{drop}$$

C.1.1 Estimate the cable voltage drop

Use either the estimation formula or the lookup table.

Estimation formula

When the lidar operates at 10 Hz under room temperature ($23 \pm 5^\circ\text{C}$), cable voltage drop can be estimated as:

$$U_{drop} = \frac{U_s - \sqrt{U_s^2 - 40r}}{2}$$

- L** Cable length (unit: m)
- r** Cable resistance (unit: Ω)
- U_s** Source voltage (unit: V)



The wire gauge of the lidar's power wire should be ≤ 26 AWG.
For 26 AWG wires, $r = 0.3L$.

Lookup table

Cable length L	Cable voltage drop		
	When $U_s = 12\text{ V}$	When $U_s = 24\text{ V}$	When $U_s = 32\text{ V}$
2 m	0.52 V	0.25 V	0.19 V
5 m	1.42 V	0.64 V	0.48 V
10 m	3.55 V (lidar's input voltage < 9 V)	1.32 V	0.97 V

As shown in the table above, when the cable length exceeds 10 m, the source voltage should be greater than 24 V.

C.1.2 Avoid overvoltage

When the lidar's input voltage approaches 32 V, make sure there is no additional overshoot in the external power system. Even a short period of overvoltage can cause irreversible damage to the lidar.

C.2 Input power

The lidar's peak power consumption is below 30 W in all operating conditions.

After a power-on in an ambient temperature below 0°C, power consumption typically remains around 15 W for a period of time.

When setting the frame rate to 20 Hz, power consumption will also be higher than the typical value in [Section 1.5 Specifications](#).

In the above or similar conditions, we recommend providing at least 30 W of input power to the lidar.

C.3 Power up/down

During power-up

The voltage requirements are shown below.

- The lidar's input voltage should remain below 1 V for more than 50 ms before ramping up.
- During the ramp-up, the input voltage should climb to 90% of its designed value in less than 500 ms.




Figure 14. Voltage requirements during power-up

During power-down

Once the lidar's input voltage falls below 1 V, it must remain below 1 V for at least 50 ms before the next power-up.

Appendix D: Optical center offset correction

D.1 Cause for correction

The distance measurements and the elevation of each channel are relative to the optical center. See the definition and position of the optical center in [Section 1.4 Channel distribution and coordinate systems](#).

As the lidar rotates, the optical center constantly changes its position, which increases the complexity of point cloud processing algorithms; by comparison, the origin of the lidar's coordinate system is a more suitable reference point.

D.2 Definition of correction

As shown in the figure below:

- O is the origin of the lidar's coordinate system.
- A is the optical center.
- B is a random data point.
- (x_{AO}, y_{AO}, z_{AO}) are the rectangular coordinates of the optical center, given in [Section 1.4 Channel distribution and coordinate systems](#).
- d_{BA} is the distance from Point B to Point A.
- ϵ_{BA} and α_{BA} are the elevation and azimuth angles of Point B relative to Point A.

For Point B, converting the spherical coordinates from $(d_{BA}, \epsilon_{BA}, \alpha_{BA})$ (relative to Point A) into (d, ϵ, α) (relative to point O) is defined as optical center offset correction.




Figure 15. Illustration of optical center offset correction

D.3 Formula

The rectangular coordinates of Point B relative to Point O:

$$x = x_{AO} + x_{BA} = x_{AO} + d_{BA} \cdot \cos(\varepsilon_{BA}) \cdot \sin(\alpha_{BA})$$

$$y = y_{AO} + y_{BA} = y_{AO} + d_{BA} \cdot \cos(\varepsilon_{BA}) \cdot \cos(\alpha_{BA})$$

$$z = z_{AO} + z_{BA} = z_{AO} + d_{BA} \cdot \sin(\varepsilon_{BA})$$

Convert rectangular coordinates to spherical coordinates:

$$d = \sqrt{x^2 + y^2 + z^2}$$

$$\varepsilon = \arcsin\left(\frac{z}{d}\right)$$

$$\alpha = \arctan\left(\frac{x}{y}\right)$$

Appendix E: Legal notice

Copyright © 2017-2026 Hesai Technology Co., Ltd.

All rights reserved. Use or reproduction of this manual in parts or its entirety in any form or by any means without the written authorization of Hesai is prohibited.

Hesai Technology makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability, or fitness for any particular purpose. Further, Hesai Technology reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revisions or changes.

HESAI and HESAI logo are registered trademarks of Hesai Technology. All other trademarks, service marks, and company names in this manual or on Hesai's official website are properties of their respective owners.

The software included in this product contains copyright that is registered under Hesai Technology. Any third party is not permitted, except as expressly permitted by the licensor or expressly required by applicable law, to decompile, reverse engineer, disassemble, modify, rent, lease, loan, distribute, sublicense, create derivative works based on the whole or any part of the software.

Hesai Product Warranty Service Manual is on the Warranty Policy page of Hesai's official website: <https://www.hesaitech.com/warranty-policy/>

Hesai Technology Co., Ltd.

Phone: +86 400 805 1233

Website: www.hesaitech.com

Address: Building A, Haisu Culture Plaza, Shanghai, China

Business Email: info@hesaitech.comService

Email: service@hesaitech.com